

EX11 SERIES



PRO
The Power of Innovation®

Installation Guide



Cut Cable Squarely



Using a fixed blade prep tool in good condition, prepare cable to 1/4" x 1/4" dimensions



Ensure cable is prepared to 1/4" x 1/4" dimensions



Ensure there is no dielectric, braid or foil wrapped around center conductor. Fold back braid.



If tri-shield or quad, remove outer layer of foil



Fold back inner braid



Align center conductor and dielectric with marking grooves on connector body



Mark cable at the base of the connector with thumbnail or other marking device



Insert cable into connector push firmly while rotating clockwise until the connector reaches the mark on the jacket.



Properly seated connector ready for compression



Visually inspect to ensure connector is fully compressed. Tighten to recommended torque.

